


5019 611 01000

PRODUCT SHEET

GB

Refrigerator compartment controls (depending on the model)


- A.** Thermostat knob.
- B.** Green LED: indicates that the appliance is ON. If the LED blinks, contact the After-sales Service.
- C.** Button.
- D.** Thermostat knob setting indicator.
- E.** Display indicating the set temperature. If the display indicating the set temperature blinks, contact the After-sales Service.
- F.** ON/OFF button.
- G.** Temperature selection button.

The refrigerator can operate at ambient temperatures between +10°C and +38°C. Optimal performance is obtained at temperatures between +16°C and +38°C.


Note: The ambient air temperature, the frequency of door opening and the position of the appliance can affect the internal temperatures of the refrigerator. These factors must be taken into account when setting the thermostat.

Replacing the bulb (models with glass door)

When the bulb is faulty or broken, request a replacement from our authorised personnel (After-sales Service).



Replacing the bulb (model with metal door)



1. Loosen the screw and remove the lamp cover.
2. When replacing the bulb, bear in mind that this appliance is fitted with a special bulb (15W with bayonet fitting); to replace do not unscrew, but pull towards the inside of the appliance (as indicated by the arrow).
3. Refit the lamp cover and secure it with the screw.

Printed in Italy 08/05

D GB F NL E P I GR S N DK FIN PL CZ SK H RUS BG RO